

# INSTRUCTIONS FOR CANDY FLOSS MACHINE

- Pre-mix colour/flavour and sugar. 1 Sachet does 5kg of sugar (extra colour/flavour sachets are available from us).
- Wet around inside of bowl with a damp cloth. Fill the head with the sugar mixture. Use a plastic beaker.
- Turn on motor switch.
- Turn on element switch and set heat control knob so that the pointer is in the floss position.
- Wait about 4 minutes until the element heats up and the floss starts to flow. If the heat is too hot it will not floss properly and smoke. **Reduce the heat.**
- When adding sugar turn motor off, wait for spinning to stop. Fill with sugar, turn motor back on. **Do not use glass or metal.**
- If you want to stop in between times leave the motor running and just turn the heat control down until the floss stops. This keeps the element warm for the restart of floss. **Do not stop the motor without letting the element cool down first.**
- Before stopping the machine **always** turn the heat control knob off and wait 3 minutes for the element to cool then turn the motor switch off.  
**Do not stop the motor without letting the element cool first.**
- Once you have finished with the floss please spin machine until all the sugar has been used up and then wash bowl with warm water. **Do not put water on spinning head or remove head from machine.**
- The bowl must be clean upon return or an extra charge will be made.

